




### Power




### Interface





### Option




### PWRKEY




### SIM\_CAR




### UART




### SIM800X GSM/GPRS HAT



### Antenna



### USB



### Raspberry Interface